



CG4002: HARDWARE – SENSORS AND FPGA

SANGIT SASIDHAR



SANGIT@NUS.EDU.SG



E2-02-29



66015997

HARDWARE SENSORS REQUIREMENTS

- Detect Dance Moves!!!!
- Design your own dance moves
- Design a Body Analytics System using EMG
- Power System Design

HUMAN MOVEMENT ESTIMATION


- What is motion capture?



- How do we do it?
 - Optical Systems
 - Non-Optical Systems

OPTICAL SYSTEMS

- Optical systems utilize data captured from image sensors to triangulate the 3D position of a subject between two or more cameras calibrated to provide overlapping projections
- Marker Based System
- Markerless System



NON-OPTICAL SYSTEMS

- Inertial Systems

- miniature inertial sensors
- biomechanical models
- sensor fusion algorithms
- \$1,000 to \$80,000 USD



- Mechanical motion

- exoskeleton motion capture systems
- \$25,000 to \$75,000 USD



DETECT DANCE MOVES!!!



- What type of parameters need to be measured?

- Hand movements
- Leg movements
- Body movements
- Joint movements



DETECT DANCE MOVES!!!


- What type of sensors can we use?



SENSORS- MOVEMENT DETECTION

- CAMERA

- Image Processing
- Amateur processor
- Noisy data
- No depth information
- Visual Occlusion




- FLEX SENSORS

- Joint angle
- Amateur processor
- Noise free data
- No other information
- 1 DOF




- IMU/ACCELEROMETER

- Acceleration, tilt, angles
- Good processor
- Some noise
- Holistic information
- 3/6/9 DOF



SENSOR MEASUREMENT PROTOCOL


- IMU Signal



- Sampling – IMU Signal Processing
 - Filtering: Remove noise from the signal
 - Conversion of raw data to appropriate format (e.g. Hex value to m/s^2 for acceleration)
- Feature Extraction
 - Example Sampling Frequency: 5-50 Hz
 - Analysis Window: 250ms – 1000ms
 - 500 ms contains 25 samples per sensor
 - Use of sliding window ?

SENSOR MEASUREMENT PROTOCOL


- Benefits of Feature Extraction on the Bluno



- Communication protocol is simpler
 - 1 second window: 6 sensors/IMU * 2 IMUs per user * 50 samples/1 second = 600 samples
 - Extracting features: e.g. 6 features per sensor * 6 sensors/IMU * 2 IMUs per user = 72 features
- Utilization of the Bluno resources
- Decentralized Debugging of sensors and each body unit is easier and convenient

BEETLE BLUNO

- The Beetle BLE (Former name as Bluno Beetle) is an Arduino Uno based board with bluetooth 4.0 (BLE)
- ATmega328@16MHz
- Bluetooth Low Energy (BT 4.0)
- Micro USB port
- Super Compact Size
- Support Bluetooth HID and ibeacon
- Support Wireless Programming




- Digital Pin x4
- Analog Pin x4
- PWM Output x2
- UART interface x1
- I2C interface x1
- Micro USB interface x1
- Power port x2
- Weight: 10g

Source: https://www.dfrobot.com/index.php?route=product/product&product_id=1259&search=beetle&description=true&category_id=48&gclid=Cj0KCQiAsbrxBRDpARIsAAnnz_MokTwqL2LxM-OZI0JIzV2S_zNbUMkXhpnIkH734XtveQnhZ3dNII MaAu-UEALw_wcB

EMG MEASUREMENT PROTOCOL

- ELECTROMYOGRAPHY (EMG)




EMG MEASUREMENT PROTOCOL

- Example Muscle Groups


Motion of the Hand	Associated Muscle Group
Elbow Flexion and Extension	<i>biceps brachii</i>
Wrist Flexion and Extension	<i>flexor carpi ulnaris</i>
Hand Grasp and Open	<i>flexor digitorum profundus</i> <i>flexor digitorum superficialis</i>

- Electrode Placement

- *biceps brachii* : The midline of the muscle belly.
- *flexor carpi ulnaris* :




- *flexors of the fingers* :



EMG MEASUREMENT PROTOCOL


- EMG Signal Processing
 - Power Spectral Density



- Sample – EMG Signal Processing
 - Low Pass Filter:
 - Type: 2nd Order Butterworth Filter
 - Cut-Off Frequency: 350 Hz
 - High Pass Filter:
 - Type: 2nd order Butterworth Filter
 - Cut-Off Frequency: 10 Hz
 - Sampling Rate: $> 2 \times$ Highest frequency in the signal
 - EMG Equipment: MyoWare Muscle Sensor

EMG MEASUREMENT PROTOCOL

- MyoWare Muscle Sensor (Source- Sparkfun)




EMG MEASUREMENT PROTOCOL

- EMG MEASUREMENT

- Skin Preparation → Alcohol Swabs to clear the skin of dirt and debris
- Electrode Configuration:
 - Bipolar Electrode Configuration with Ground Electrode
 - Eg. - Ground Electrode Site: Elbow Joint

- Feature Extraction

- Example Sampling Frequency – 1000 Hz
- Analysis Window → 500 ms
- 500 ms containing 500 Samples
- Moving Window → 250 ms



METHODOLOGY

- Feature Set of Tim-Frequency Features

- Mean Absolute Value $\rightarrow \overline{x_i} = \frac{1}{N} \sum_{k=1}^N |x_k|$

- Mean Absolute Value Slope $\rightarrow \Delta \overline{x_i} = \overline{x_i} - \overline{x_{i-1}}$

- Zero Crossings

- Slope Sign Changes

- Waveform Length $\rightarrow l_0 = \sum_{k=1}^N \Delta x_k$ where,


$$\Delta x_k = x_k - x_{k-1}$$

- Feature set using Wavelet Analysis

- Wavelet Decomposition

V_j	=	W_{j+1}	\oplus	V_{j+1}		
	=	W_{j+1}	\oplus	W_{j+2}	\oplus	V_{j+2}
	=				

- Wavelet Entropy $\rightarrow E = \sum_{j=1}^L |d_j(k)|^2$
 where $d_j(k)$ is the wavelet coefficient



POWER SYSTEM DESIGN

- Why Power System Design



VS




VS




- How Big a Battery do you actually need?

POWER BUDGET AND BATTERY DESIGN

- Subsystems in Series $P_{in} = \frac{P_{out}}{\eta_1 \cdot \eta_2 \cdot \eta_3}$



- Subsystems in Parallel $P_{in} = P_{in1} + P_{in2} + P_{in3}$




- Subsystems in Series and Parallel

PS: Sample battery design video also has been uploaded

BEETLE POWER OPTIONS

- Button Cell Battery
 - Small, Portable, Lightweight
 - High running cost, does not last long
- AA Battery
 - Relatively small, can be integrated to the body sensor system, rechargeable
 - Unregulated voltage, requires voltage regulator or DC-DC convertor



INTERFACING INFO - GPIO, I2C, UART

- General Purpose Input/Output (GPIO) – configure a pin as output / input and write/read digital data to the pin

Eg : simple devices such as ultrasound, IR, 2-line LCD display

- Inter-integrated circuit (I2C) – 2 wire, synchronous, serial, master-slave, half-duplex, in-band addressing using 7-bit addresses (+read/write bit), short-distance [Arduino Library :Wire]

Eg : Slower devices such as accelerometer, gyro, compass etc.

- Universal asynchronous receiver/transmitter (UART, also simply called serial) – 2 non-shared wires, asynchronous, serial, full-duplex, longer distance (using a physical layer) [Library : Serial]

Eg : Between computers / microcontrollers, RFID modules, GSM modules

INTERFACING INFO

- Take note of the voltage levels of each device and component(3.3V / 5V/12V etc)
 - Do you require level shifting between 3.3V sensors and 5V Blunos?
- Take note of the max. current supplied by each pin of the device
- Read the datasheet carefully for such info
- Damaged Ultra96 / Bluno will be replaced, but the cost will be deducted from your budget !!
- You have to be careful about **endianness*** used by the two devices being interfaced


*If **L**east significant byte occupies the **L**owest address, it's **L**ittle-endian

HW FPGA REQUIREMENTS

- HW FPGA to do inference while SW ML to take care of training
- Implement 1 specific neural network inference model onto the FPGA
- Run the model with the test data provided
- Evaluate the hardware utilization, timing and power requirements
- Use C++ High Level Synthesis (HLS)

ULTRA96 - FEATURES

SoC	Xilinx Zynq UltraScale+ MPSoC ZU3EG A484
RAM	Micron LPDDR4 memory provides 2 GB of RAM in a 512M x 32 configuration
Storage	Delkin 16 GB microSD card + adapter
Wireless	802.11b/g/n Wi-Fi and Bluetooth 4.2 (provides both Bluetooth Classic and Low Energy (BLE))
USB	1x USB 3.0 Type Micro-B upstream port 2x USB 3.0, 1x USB 2.0 Type A downstream ports
Display	Mini DisplayPort (MiniDP or mDP)



PYNQ™

AVNET™
Reach Further™

Ultra96

64-bit Arm architecture coupled
with Xilinx programmable logic

python™


XILINX

/ ULTRA96


Boards

NEURAL NETWORKS ON FPGA – SAMPLE IMPLEMENTATIONS


CNN on FPGA




MLP with ReLU activation function



MLP with tanh activation function



HARDWARE FPGA DESIGN



NEURAL NETWORK IMPLEMENTATION


- Convolution and Linear Layer

$$\text{Output} = \text{bias} + (\text{input} \cdot \text{weight})$$

where;

- $\text{input} = 1 \times i$ vector of input features
- $\text{weight} = i \times j$ vector of weights
- $\text{bias} = 1 \times j$ vector of biases
- $\text{output} = 1 \times j$ vector of neuron outputs

➔ Matrix multiplication



ACTIVATION FUNCTION: RELU FUNCTION

- ReLU : Rectified Linear Unit
- Simple Calculation:

```
if input > 0:  
    return input  
else:  
    return 0
```

- Can be implemented in the FPGA using Look Up Tables (LUTs)

FIXED POINT DATA TYPE

- IPs data streams are 32-bit floats → compiler needs to synthesise hardware for floating point operations
- Vivado HLS has “ap_fixed” data type for fixed point conversion and quantisation of data
- Fixed point Conversion: Requires checking for absolute maxima and minima of all the data
- Quantisation: reduces the precision of the data → may affect prediction accuracy
- Precision loss is evaluated at each layer level and at the model level to find a small enough bit-width

EVALUATION

- Evaluation of the inference model and its comparison to the software ML implementation
- Hardware co-simulation at the HLS stage
- Optimization of the design using parallelization and pipelining
- Hardware Utilization: BRAM, DSP, FF, LUT
- Ultra96 Power Consumption Measurement:
https://github.com/Avnet/Ultra96-PYNQ/blob/master/Ultra96/notebooks/common/ultra96_pmbus.ipynb

IMPORTANT SAFETY INFO

- Follow all the lab safety rules (**non-negotiable**)
- Be responsible for your own safety as well as that of people around you
- Always use a regulated, fused power source to power your project
- You need a battery to power the final system (for it to be wearable)
 - The battery specs would depend on the components you are using
 - If possible, try and use NiMH battery packs
 - Be **VERY VERY** careful with **Li-ion** / **LiPo** batteries
 - They can explode if you overcharge, charge faster than the recommended rate/current, charge using a charger not designed for it, draw excessive current, subject it to mechanical stress
 - Use it only if you are very careful and confident. Never charge unattended or attempt disassembly

DOCUMENTATION

- A proper documentation is very useful in debugging
- Document everything in a wiki / knowledge bank (eg: NUS wiki, GIT, Microsoft Teams)
 - Include the links. Always have wiki open whenever you google
 - Save all the datasheets, libraries you used (you need to specify the library source in your code clearly)
- Will help you in final documentation. It will also serve as a learning journal
- “Oh, I had seen it somewhere, can’t recall where” issues can be minimized

The background features a light beige to olive green gradient. In the corners, there are decorative circuit-like patterns. The top-left and top-right corners have dark blue lines with small circles at the ends. The bottom-left and bottom-right corners have light green lines with small circles at the ends.

THANK YOU